

Manual, Warning and Safety Information Matias wireless Bluetooth keyboards (all models beginning with FK408BT and FK418BT)

## Use

Keyboard Layout: Make sure the keyboard layout matches your language settings (for example, QWERTY).

## Maintenance

Cleaning: Clean the keyboard regularly with a dry cloth to prevent accumulation of dust and dirt. Avoid water or harsh cleaning agents.

Battery management: Charge the keyboard regularly to avoid battery problems.

## Troubleshooting

No connection:  
slow respons: Reset the keyboard by turning it off and reconnecting it.  
Check if the battery is low and charge it if necessary.

**Charging:** **Fully charge the keyboard before first use!**

Use the included USB cable to charge the keyboard. Plug the charging cable into the keyboard, then connect it to your computer or a USB power adapter.

	FK408BT	FK418BT
In the box	<ul style="list-style-type: none"><li>• Keyboard</li><li>• Manual</li><li>• Charging Cable</li></ul>	<ul style="list-style-type: none"><li>• Keyboard</li><li>• Manual</li><li>• Charging Cable</li></ul>
Dimensions	14.06" x 4.58" x 0.75" (35.7 x 11.6 x 1.9 cm)	17.35" x 4.58" x 0.75" (44.1 x 11.6 x 1.9 cm)
System requirements	<ul style="list-style-type: none"><li>• PC or Mac with Bluetooth®</li></ul>	<ul style="list-style-type: none"><li>• PC or Mac with Bluetooth®</li></ul>
Battery life	Up to 1 year*	Up to 1 year*

\*Battery life depends on usage


## How to connect

Pairing to a Mac	Pairing with Windows
1) On your Mac select... menu > System Preferences > Keyboard 2) Click Setup Bluetooth Keyboard... 3) Hold down one of the 4 Pairing keys until it starts flashing Blue. 4) When the keyboard is found, click Continue and follow the onscreen instructions.	1) Hold down the Control key and one of the 4 Pairing keys until it starts flashing Blue. 2) Follow the keyboard pairing process for the version of Windows or Android on your device.
Function keys on Mac/iOS	Function keys on Windows Android
F1 - Screen darker	Fn F7 - Previous track
F2 - Screen Brighter	Fn F8 - Play / Pause
F3 - Mission control (Mac) Search (iOS)	Fn F9 - Next track
F4 - LaunchPad (Mac) Home Button (iOS)	Fn F10 - Mute
F5 - Lock button (iOS)	Fn F11 - Volume down
F6 - show / Hide onscreen keyboard (iOS)	Fn F12 - Volume up
F7 - Previous track	
F8 - Play / Pause	F13 - Print screen
F9 - Next track	F14 - Scroll lock
F10 - Mute	F15 - Pause
F11 - Volume Down	
F12 - Volume Up	Fn Delete ☒ - insert
Control ⌘ - Shutdown options (Mac)	Clear - Num Lock
F13 - Save screen image to Photos (iOS)	
Shift ⌘ 3 - Save screen image to Desktop (Mac)	
Control ⌘ F - Full screen view (Mac)	
Control ⌘ D - Dictionary (Mac)	

How the FN key works on Mac



If you need to type **F1** (rather than darken the screen) simply hold down **fn** and then press **F1**

If this is not convenient, you can reverse it. Go to...  
 menu > **System Preferences...** > **Keyboard**  
 and check the box, as shown below

☒ Use all F1, F2, etc. keys as standard function keys  
 When this option is selected, press the Fn key to use the special features printed on each key.

## Need help?

Contact us at: [support@matias.eu](mailto:support@matias.eu)

## Warranty Procedure

1. Contact your reseller and provide a detailed description of the problem.
2. They will try to solve your problem and handle your request accordingly

Matias Corporation ("Matias") warrants to the original end user ("Customer") that this product will be free from defects in workmanship and materials, under normal use, for 1 year from the date of original purchase from Matias or its authorized reseller. Matias' sole obligation under this express warranty shall be (at Matias' option and expense) to repair or replace the product or part with a comparable product or part. All products or parts that are replaced become the property of Matias.

### LIMITATION OF LIABILITY

To the full extent allowed by law, Matias excludes for itself and its suppliers any liability (whether based in contract or in tort, including negligence) for incidental, consequential, indirect, special or punitive damages of any kind, or for loss of revenue or profits, loss of business, loss of information or data, or other financial loss arising out of or in connection with the sale, installation, maintenance, use, performance, failure, or interruption of this product, even if Matias or its authorized reseller has been advised of the possibility of such damages, and limits its liability to replacement, repair, or refund of the purchase price paid, at Matias' option.

This disclaimer of liability for damages will not be affected if any remedy provided herein shall fail of its essential purpose.

This keyboard contains no user-serviceable parts, and should not be opened or disassembled – risking damage to it and injury to you. Do NOT remove, crush, or puncture the battery inside, or expose it to high temperatures or liquids. When this product reaches its end of life, please dispose of it according to your local environmental laws and guidelines. The lithium-ion battery in the keyboard should be recycled or disposed of separately from household waste, by a qualified

service provider. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference.
- 2) This device must accept any interference received, including interference that may cause undesired operation.

Complies with the Canadian ICES-003 Class B specifications.

This product complies with the requirements of European Directives 72/23/EEC, 89/336/EEC, and 1999/5/EC.

Copyright © 2024 Matias Corp. All rights reserved. Matias Wireless Aluminum Keyboard, Matias, and the Matias logo are trademarks of the Matias Corporation.

Launchpad, Mission Control, Mac, iOS, iPad, iPhone, iPod touch, Apple, and the Apple logo are trademarks of Apple Inc. Windows is a trademark of Microsoft Corporation.

Android is a trademark of Google Inc.

Bluetooth is a registered trademark of Bluetooth SIG, Inc.

Owners of other trademarks are respectfully acknowledged.